

DILMP Complete Parts List

109903	DILMP125 (RAC120)	Contactor
109904	DILMP125 (RAC24)	Contactor
109905	DILMP125 (RAC240)	Contactor
109906	DILMP125 (RAC440)	Contactor
109906	DILMP125 (RAC440)	Contactor
109907	DILMP125 (RAC48)	Contactor
109907	DILMP125 (RAC48)	Contactor
109908	DILMP125 (RAC500)	Contactor
109908	DILMP125 (RAC500)	Contactor
109909	DILMP125 (RDC130)	Contactor
109909	DILMP125 (RDC130)	Contactor
109910	DILMP125 (RDC24)	Contactor
109911	DILMP125 (RDC240)	Contactor
109911	DILMP125 (RDC240)	Contactor
109912	DILMP125 (RDC60)	Contactor
109912	DILMP125 (RDC60)	Contactor
109913	DILMP160 (RAC120)	Contactor

109914	DILMP160 (RAC24)	Contactactor
109915	DILMP160 (RAC240)	Contactactor
109916	DILMP160 (RAC440)	Contactactor
109916	DILMP160 (RAC440)	Contactactor
109917	DILMP160 (RAC48)	Contactactor
109917	DILMP160 (RAC48)	Contactactor
109918	DILMP160 (RAC500)	Contactactor
109918	DILMP160 (RAC500)	Contactactor
109919	DILMP160 (RDC130)	Contactactor
109919	DILMP160 (RDC130)	Contactactor
109920	DILMP160 (RDC24)	Contactactor
109921	DILMP160 (RDC240)	Contactactor
109921	DILMP160 (RDC240)	Contactactor
109922	DILMP160 (RDC60)	Contactactor
109922	DILMP160 (RDC60)	Contactactor
276982	DILMP20 (*V50HZ)	Contactactor
276983	DILMP20 (*V60HZ)	Contactactor
276990	DILMP20 (*VDC)	Contactactor
276976	DILMP20 (110V50/60HZ)	Contactactor

276967	DILMP20 (110V50HZ,120V60HZ)	Contactactor
276962	DILMP20 (110V60HZ)	Contactactor
276988	DILMP20 (110VDC)	Contactactor
276963	DILMP20 (115V60HZ)	Contactactor
276956	DILMP20 (12V50HZ)	Contactactor
276984	DILMP20 (12VDC)	Contactactor
276968	DILMP20 (190V50HZ,220V60HZ)	Contactactor
276964	DILMP20 (208V60HZ)	Contactactor
276977	DILMP20 (220V50/60HZ)	Contactactor
276969	DILMP20 (220V50HZ,240V60HZ)	Contactactor
276989	DILMP20 (220VDC)	Contactactor
276978	DILMP20 (230V50/60HZ)	Contactactor
276970	DILMP20 (230V50HZ,240V60HZ)	Contactactor
276959	DILMP20 (240V50HZ)	Contactactor
276974	DILMP20 (24V50/60HZ)	Contactactor
276957	DILMP20 (24V50HZ)	Contactactor
276961	DILMP20 (24V60HZ)	Contactactor
276985	DILMP20 (24VDC)	Contactactor
276979	DILMP20 (380V50/60HZ)	Contactactor

276971	DILMP20 (380V50HZ,440V60HZ)	Contactator
276972	DILMP20 (400V50HZ,440V60HZ)	Contactator
276973	DILMP20 (415V50HZ,480V60HZ)	Contactator
276975	DILMP20 (42V50/60HZ)	Contactator
276966	DILMP20 (42V50HZ,48V60HZ)	Contactator
109926	DILMP200 (RAC440)	Contactator
109926	DILMP200 (RAC440)	Contactator
109927	DILMP200 (RAC48)	Contactator
109927	DILMP200 (RAC48)	Contactator
109928	DILMP200 (RAC500)	Contactator
109928	DILMP200 (RAC500)	Contactator
109929	DILMP200 (RDC130)	Contactator
109929	DILMP200 (RDC130)	Contactator
109930	DILMP200 (RDC24)	Contactator
109931	DILMP200 (RDC240)	Contactator
109931	DILMP200 (RDC240)	Contactator
109932	DILMP200 (RDC60)	Contactator
109932	DILMP200 (RDC60)	Contactator
109787	DILMP32-10 (*V50HZ)	Contactator

109788	DILMP32-10 (*V60HZ)	Contactator
109789	DILMP32-10 (110V50/60HZ)	Contactator
109789	DILMP32-10 (110V50/60HZ)	Contactator
109790	DILMP32-10 (110V50HZ,120V60HZ)	Contactator
109791	DILMP32-10 (115V60HZ)	Contactator
109792	DILMP32-10 (190V50HZ,220V60HZ)	Contactator
109792	DILMP32-10 (190V50HZ,220V60HZ)	Contactator
109793	DILMP32-10 (208V60HZ)	Contactator
109794	DILMP32-10 (220V50/60HZ)	Contactator
109794	DILMP32-10 (220V50/60HZ)	Contactator
109795	DILMP32-10 (220V50HZ,240V60HZ)	Contactator
109795	DILMP32-10 (220V50HZ,240V60HZ)	Contactator
109796	DILMP32-10 (230V50/60HZ)	Contactator
109797	DILMP32-10 (230V50HZ,240V60HZ)	Contactator
109798	DILMP32-10 (240V50HZ)	Contactator
109799	DILMP32-10 (24V50/60HZ)	Contactator
109800	DILMP32-10 (24V50HZ)	Contactator
109800	DILMP32-10 (24V50HZ)	Contactator
109801	DILMP32-10 (24V60HZ)	Contactator

109802	DILMP32-10 (380V50/60HZ)	Contactator
109803	DILMP32-10 (380V50HZ,440V60HZ)	Contactator
109803	DILMP32-10 (380V50HZ,440V60HZ)	Contactator
109804	DILMP32-10 (400V50HZ,440V60HZ)	Contactator
109804	DILMP32-10 (400V50HZ,440V60HZ)	Contactator
109805	DILMP32-10 (415V50HZ,480V60HZ)	Contactator
109805	DILMP32-10 (415V50HZ,480V60HZ)	Contactator
109806	DILMP32-10 (42V50/60HZ)	Contactator
109806	DILMP32-10 (42V50/60HZ)	Contactator
109807	DILMP32-10 (42V50HZ,48V60HZ)	Contactator
109807	DILMP32-10 (42V50HZ,48V60HZ)	Contactator
109808	DILMP32-10 (48V50HZ)	Contactator
109809	DILMP32-10 (600V60HZ)	Contactator
109810	DILMP32-10 (RDC130)	Contactator
109810	DILMP32-10 (RDC130)	Contactator
109811	DILMP32-10 (RDC24)	Contactator
109812	DILMP32-10 (RDC240)	Contactator
109812	DILMP32-10 (RDC240)	Contactator
109813	DILMP32-10 (RDC60)	Contactator

109813	DILMP32-10 (RDC60)	Contactora
109814	DILMP32-10 (TVC100)	Contactora
109815	DILMP32-10 (TVC200)	Contactora
109816	DILMP45-10 (*V50HZ)	Contactora
109817	DILMP45-10 (*V60HZ)	Contactora
109818	DILMP45-10 (110V50/60HZ)	Contactora
109818	DILMP45-10 (110V50/60HZ)	Contactora
109819	DILMP45-10 (110V50HZ,120V60HZ)	Contactora
109820	DILMP45-10 (115V60HZ)	Contactora
109821	DILMP45-10 (190V50HZ,220V60HZ)	Contactora
109821	DILMP45-10 (190V50HZ,220V60HZ)	Contactora
109822	DILMP45-10 (208V60HZ)	Contactora
109823	DILMP45-10 (220V50/60HZ)	Contactora
109823	DILMP45-10 (220V50/60HZ)	Contactora
109824	DILMP45-10 (220V50HZ,240V60HZ)	Contactora
109824	DILMP45-10 (220V50HZ,240V60HZ)	Contactora
109825	DILMP45-10 (230V50/60HZ)	Contactora
109826	DILMP45-10 (230V50HZ,240V60HZ)	Contactora
109827	DILMP45-10 (240V50HZ)	Contactora

109828	DILMP45-10 (24V50/60HZ)	Contactator
109829	DILMP45-10 (24V50HZ)	Contactator
109829	DILMP45-10 (24V50HZ)	Contactator
109830	DILMP45-10 (24V60HZ)	Contactator
109831	DILMP45-10 (380V50/60HZ)	Contactator
109832	DILMP45-10 (380V50HZ,440V60HZ)	Contactator
109832	DILMP45-10 (380V50HZ,440V60HZ)	Contactator
109833	DILMP45-10 (400V50HZ,440V60HZ)	Contactator
109833	DILMP45-10 (400V50HZ,440V60HZ)	Contactator
109834	DILMP45-10 (415V50HZ,480V60HZ)	Contactator
109834	DILMP45-10 (415V50HZ,480V60HZ)	Contactator
109835	DILMP45-10 (42V50/60HZ)	Contactator
109835	DILMP45-10 (42V50/60HZ)	Contactator
109836	DILMP45-10 (42V50HZ,48V60HZ)	Contactator
109836	DILMP45-10 (42V50HZ,48V60HZ)	Contactator
109837	DILMP45-10 (48V50HZ)	Contactator
109838	DILMP45-10 (600V60HZ)	Contactator
109839	DILMP45-10 (RDC130)	Contactator
109839	DILMP45-10 (RDC130)	Contactator

109840	DILMP45-10 (RDC24)	Contactora
109841	DILMP45-10 (RDC240)	Contactora
109841	DILMP45-10 (RDC240)	Contactora
109842	DILMP45-10 (RDC60)	Contactora
109842	DILMP45-10 (RDC60)	Contactora
109843	DILMP45-10 (TVC100)	Contactora
109844	DILMP45-10 (TVC200)	Contactora
109845	DILMP63 (*V50HZ)	Contactora
109846	DILMP63 (*V60HZ)	Contactora
109847	DILMP63 (110V50/60HZ)	Contactora
109848	DILMP63 (110V50HZ,120V60HZ)	Contactora
109849	DILMP63 (115V60HZ)	Contactora
109850	DILMP63 (190V50HZ,220V60HZ)	Contactora
109850	DILMP63 (190V50HZ,220V60HZ)	Contactora
109851	DILMP63 (208V60HZ)	Contactora
109852	DILMP63 (220V50/60HZ)	Contactora
109853	DILMP63 (220V50HZ,240V60HZ)	Contactora
109853	DILMP63 (220V50HZ,240V60HZ)	Contactora
109854	DILMP63 (230V50/60HZ)	Contactora

109855	DILMP63 (230V50HZ,240V60HZ)	Contactactor
109856	DILMP63 (240V50HZ)	Contactactor
109857	DILMP63 (24V50/60HZ)	Contactactor
109858	DILMP63 (24V50HZ)	Contactactor
109858	DILMP63 (24V50HZ)	Contactactor
109859	DILMP63 (24V60HZ)	Contactactor
109860	DILMP63 (380V50/60HZ)	Contactactor
109861	DILMP63 (380V50HZ,440V60HZ)	Contactactor
109861	DILMP63 (380V50HZ,440V60HZ)	Contactactor
109862	DILMP63 (400V50HZ,440V60HZ)	Contactactor
109862	DILMP63 (400V50HZ,440V60HZ)	Contactactor
109863	DILMP63 (415V50HZ,480V60HZ)	Contactactor
109863	DILMP63 (415V50HZ,480V60HZ)	Contactactor
109864	DILMP63 (42V50/60HZ)	Contactactor
109864	DILMP63 (42V50/60HZ)	Contactactor
109865	DILMP63 (42V50HZ,48V60HZ)	Contactactor
109865	DILMP63 (42V50HZ,48V60HZ)	Contactactor
109866	DILMP63 (48V50HZ)	Contactactor
109867	DILMP63 (600V60HZ)	Contactactor

109868	DILMP63 (RDC130)	Contactora
109868	DILMP63 (RDC130)	Contactora
109869	DILMP63 (RDC24)	Contactora
109870	DILMP63 (RDC240)	Contactora
109870	DILMP63 (RDC240)	Contactora
109871	DILMP63 (RDC60)	Contactora
109871	DILMP63 (RDC60)	Contactora
109872	DILMP63 (TVC100)	Contactora
109873	DILMP63 (TVC200)	Contactora
109874	DILMP80 (*V50HZ)	Contactora
109875	DILMP80 (*V60HZ)	Contactora
109876	DILMP80 (110V50/60HZ)	Contactora
109876	DILMP80 (110V50/60HZ)	Contactora
109877	DILMP80 (110V50HZ,120V60HZ)	Contactora
109878	DILMP80 (115V60HZ)	Contactora
109879	DILMP80 (190V50HZ,220V60HZ)	Contactora
109879	DILMP80 (190V50HZ,220V60HZ)	Contactora
109880	DILMP80 (208V60HZ)	Contactora
109881	DILMP80 (220V50/60HZ)	Contactora

109881	DILMP80 (220V50/60HZ)	Contactora
109882	DILMP80 (220V50HZ,240V60HZ)	Contactora
109882	DILMP80 (220V50HZ,240V60HZ)	Contactora
109883	DILMP80 (230V50/60HZ)	Contactora
109884	DILMP80 (230V50HZ,240V60HZ)	Contactora
109885	DILMP80 (240V50HZ)	Contactora
109886	DILMP80 (24V50/60HZ)	Contactora
109887	DILMP80 (24V50HZ)	Contactora
109887	DILMP80 (24V50HZ)	Contactora
109888	DILMP80 (24V60HZ)	Contactora
109889	DILMP80 (380V50/60HZ)	Contactora
109890	DILMP80 (380V50HZ,440V60HZ)	Contactora
109890	DILMP80 (380V50HZ,440V60HZ)	Contactora
109891	DILMP80 (400V50HZ,440V60HZ)	Contactora
109891	DILMP80 (400V50HZ,440V60HZ)	Contactora
109892	DILMP80 (415V50HZ,480V60HZ)	Contactora
109892	DILMP80 (415V50HZ,480V60HZ)	Contactora
109893	DILMP80 (42V50/60HZ)	Contactora
109893	DILMP80 (42V50/60HZ)	Contactora

109894	DILMP80 (42V50HZ,48V60HZ)	Contactator
109894	DILMP80 (42V50HZ,48V60HZ)	Contactator
109895	DILMP80 (48V50HZ)	Contactator
109896	DILMP80 (600V60HZ)	Contactator
109897	DILMP80 (RDC130)	Contactator
109897	DILMP80 (RDC130)	Contactator
109898	DILMP80 (RDC24)	Contactator
109899	DILMP80 (RDC240)	Contactator
109899	DILMP80 (RDC240)	Contactator
109900	DILMP80 (RDC60)	Contactator
109900	DILMP80 (RDC60)	Contactator
109901	DILMP80 (TVC100)	Contactator
109902	DILMP80 (TVC200)	Contactator